

WARNINGS AND SAFETY PRECAUTIONS

The following statements are warnings and safety precautions for the installation, operation, and maintenance of the Aladdin Storage Lift. Closely follow the installation guide when installing the Aladdin Storage Lift. Please contact technical support (877) 287-4601 with any questions or concerns regarding the following:

1. The Aladdin Storage Lift is to never be used to transport humans in any way.
2. Do not install a storage lift where there is no human access to the attic such as an attic pull down or staircase.
3. The ceiling height must be specified when ordering the Aladdin Storage Lift.
4. Never allow the cart cable counter weights to touch the floor. If they touch the floor the cables will not wind properly. Contact Aladdin Storage Lift technical support for assistance. (877) 287-4601
5. Avoid damage to the ceiling, storage lift, and load by making sure the load placed inside the cart assembly does not extend outside the inner frame.
6. Do not load the cart assembly with more than 500lbs.
7. Do not install the storage lift outdoors.
8. The storage lift should be framed in on a level plane.
9. Never sit or stand under the cart assembly while operating the storage lift.
10. Never operate the Aladdin storage lift without the cart assembly attached to the cart cables. This can cause the cart cables to jump off the Drive Shaft, causing a safety hazard. If this situation occurs, contact Aladdin Storage Lift technical support immediately. (877) 287-4601
11. Never fully extend the cart cables from the Aladdin Storage Lift. This could cause the cable to become reversed on the Drive Shaft. See owner's manual for supplied cable length.
12. Always disconnect the power source from the storage lift when servicing or performing maintenance.
13. Never cut or adjust the length of the cart cables.

WARNINGS AND SAFETY PRECAUTIONS

14. Always make sure the height of your load does not exceed the attic ceiling height.
15. Never install an Aladdin Storage Lift where the ceiling height exceeds the cart cable lengths. This can cause the cart cables to become reversed on the Drive Shaft, causing a safety hazard. If this situation occurs, contact Aladdin Storage Lift technical support immediately. (877) 287-4601
16. Do not operate the storage lift unless the cart cables are in the Drive Shaft spool grooves.
17. Periodically inspect the cart cables for frays or kinks. If a fray or kink is detected, contact Aladdin Storage Lift technical immediately. (877) 287-4601
18. Periodically inspect the worm gear drive and replace the axel grease if necessary.
19. Periodically inspect the 'plunger style' Limit Switch and make sure the screws are tight.
20. Do not install a storage lift where the load height will exceed the attic ceiling height.
21. Never alter the Aladdin Storage Lift from its original state.